# **COVERALL CLEAN** FOR «CLEAN ROOMS»

The COVERALL CLEAN goggles have been especially developed to guarantee high protection & comfort in risky environments, like pharmaceutics, micro-electronics or even surgery departments.

### 





COVACLAVE





### // COVACLAVE

- + CLEAN ISOPRENE STRAP
- + OVERFLOW CHUTE FOR LIQUIDS
- + FITS OVER PRESCRIPTION GLASSES
- TPR FRAME / UPPER INDIRECT VENTILATION / SEALED IN THE LOWER PART
- + HIGH-COMFORT AUTOCLAVABLE GOGGLE

## 5555

COVACLEAN



### // COVACLEAN

- + CLEAN ISOPRENE STRAP
- + OVERFLOW CHUTE FOR LIQUIDS
- + FITS OVER PRESCRIPTION GLASSES
- + PVC FRAME / UPPER & LOWER INDIRECT VENTILATION



# COVERALL CLEAN FOR «CLEAN ROOMS»

MODEL	VERSIONS	REFERENCES	LENS MARKING	FRAME MARKING	COATINGS
COVERALL CLEAN	Vented	COVACLEAN	≦ Z87 + U6	🗁 Z87 + D3 D4	ASAF
	Semi-vented	COVACLAVE	≦ Z87 + U6	🗁 Z87 + D3 D4	Anti-scratch/Anti-fog (+>)

#### LENS MARKING

• Crown = Manufacturer Mark

• Z87+ = Impact rated for Plano product - tested and approved to ANSI Z81.1-2015

- Lens type
- = none
- Clear Welding
- UV filter
- = W and Shade number from 1,3 to 14
- = U and scale number from 2 to 6 = L and scale number from 1,3 to 10
- Visible light filter • IR filter
- = R and scale number from 1n3 to 10
- Variable tint
- Special purpose

TECHNOLOGY

= V = S

A WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

This permanent coating on both sides of the lens gives them a high resistance to scratching (1.4 cd / m<sup>2</sup>), to the most aggressive chemicals and delays the onset of fogging for 2 minutes. In all circumstances and at all times the PLATINUM lens

innovation guarantees your eyes improved protection.

#### FRAME MARKING

- Crown = Manufacturer Mark
- Z87+ = Impact rated for Plano product tested and approved to ANSI Z81.1-2015
  - Splash/droplet protection = D3
  - Nuisance Dust protection = D4
  - = D5
- Fine Dust protection
- Country of origin = Taiwan

ANSI: guaranteed minimum resistance of the protective eyewear against everyday risks including dropping the protective eyewear onto the ground, ageing by light exposure, exposure to heat or corrosion etc.

Maximum protection for glasses. Use for high speed particles at extreme temperatures.

#### Bollé Safety product approval certificates to ANSI standards will be sent on request.

### CLEANING AND STORAGE

CLEANING: The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

MAINTENANCE: Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the glasses or goggles in a microfiber pouch or rigid case.

STORAGE: All products must be stored in a dry and clean environment.

CHARACTERISTICS				
LENSES	PC - 2,2 mm - Curve 4			
FRAME	PVC (CLEAN) / TPR (CLAVE)			
TEMPLES	Non applicable			
STRAP	Adjustable - Isoprene			
FOAM	No			
MAINTENANCE AND Cleaning	Soapy water			
STERILIZATION COVACLAVE	121° / 20 mn / 50 Cycles			

01/2021



PACKAGING AND EAN 13 CODE						
	COVACLEAN	COVACLAVE				
Individual plastic bag	3660740007850	3660740000646				
5 safety goggles per box	3660740107857	3660740100643				
90 safety goggles per outer pack	3660740207854	3660740200640				



 $\otimes$ 

Bollé Safety USA 2810 Caribou Court, Suite 160 Carlsbad, CA 92010 salesUSA@bolle-safety.com

bollesafety-usa.com